TAXITRONIC IR80

USER MANUAL

ÍNDICE GENERAL
2

1. Specific functions of the device

The printer can turn on/off by pressing the ⏻icon (If the taximeter is on, the printer will not be allowed to turn off). The printer will turn on/off automatically as the taximeter status does.

The printer will feed the paper by pressing the 🖶icon

2. Printing functions

The tickets are printed through each taximeter, you must see the user manual of the taximeter your printer is connected to, in order to know the methods and the printing options

3. Changing the paper roll

3.1. Raise the printer cover by using the opening mechanism:

3.2. Place the paper in the printer housing as the following image

3.3. Close the printer cover, leaving the paper as shown in the following image, and cut off the excess paper:

It is recommended to use the paper approved by the manufacturer.